


SPIN



Assembly instructions
Instructions de montage

el torrent

EL TORRENT IL·LUMINACIÓ S.L.

C/ Curreró 8, 17830
Mieres (Girona) Spain

T. +34 972 680 291
F. +34 972 680 011
eltorrent@eltorrent.com

www.eltorrent.com

Light for outdoor use
Luminière pour usage extérieur

Tension d'entrée: 120V - 60Hz
Input voltage: 120V - 60Hz

LED included



Protected against solid objects over 12mm
Protegido contra objetos sólidos de mas de 12mm.

Class I. Normal isolation and ground.
Clase I. Aislamiento normal y toma tierra.

Caution high voltage.
Precución alto voltaje

This product should not go to general waste container,
it should be handed in at a collection point for recycling
of electrical and electronic equipment.
*Este producto no debe ir a contenedor de basura general,
sino a recogida selectiva de equipos eléctricos y electrónicos.*

IP20




Gracias para comprar nuestro producto.
Desearnos que sea de su agrado.

Thanks for buying our product.
We hope you will enjoy it.


Disconnect the power supply before beginning the installation of the luminaire. To mount the luminaire to the ceiling, make sure to **use the most suitable fastening elements** according to the type of installation surface.
Carefully read the manual before starting the installation and **keep these instructions** for future reference.
Do not disassemble or attempt to repair the luminaire. Any alterations may void the manufacturer's warranty.
The light source should only be **replaced by a professional.**
Metal, glass, and other parts of the device can be cleaned with a **damp cloth** and **mild detergent**.

Desconecte el suministro eléctrico antes de iniciar la instalación de la luminaria.
Para fijar la luminaria al techo, asegúrese de **utilizar los elementos de sujeción más adecuados** según el tipo de superficie de instalación.
Lea detenidamente el manual antes de comenzar la instalación y **conservé estas instrucciones** para futuras referencias.
No desmonte ni intente reparar la luminaria. Cualquier alteración puede invalidar la garantía del fabricante.
La fuente de luz debe ser **reemplazada únicamente por un profesional.**
Las superficies de metal, vidrio y otras partes del aparato pueden limpiarse con **un paño húmedo y un detergente suave.**

1




2




Adjusted the height / Ajustar la altura

3



4



5

